
ATLAS EOS 2.5 TO DE LA RESERVICIO DE LA



Product Safety Information & User Instructions.





01] Safety Information

Heed all warnings.

Follow all instructions.

Do not use this apparatus near water.

Clean only with dry cloth.

Do not block any ventilation openings.

Install in accordance with the manufacturer's instructions

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarised or grounding type plug.

A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety.

If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.*

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel.

Servicing is required when the power-supply cord or plug has been damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

POWER SOURCES

Connect the apparatus to a power supply only of the type described in the operating instructions or marked on the apparatus.

MAINS POWER CABLES

Disconnect the apparatus from the mains supply via the mains plug. The mains plug must be accessible at all times.

*Atlas recommend Eos power cables for optimum performance with this unit.

These or equivalent power cables can be obtained from your retailer.

Warning: this appliance must be earthed.



**Maximum supply from Eos 2.5em Modular power distribution unit is 10A in countries where the power supply is 230v. Internal fuse is of 10A rating, this value should NOT be exceeded.

In countries where the power supply is 120v, the maximum current supply should not exceed 15A. In this case a 15A fuse is factory fitted.

Objects and liquid entry.

Do not let objects or liquids fall into the apparatus or expose the apparatus to dripping or splashing. Do not place a vessel containing liquid on top of the apparatus.

No naked flame sources, such as lighted candles, should be placed on the apparatus.

The apparatus has been designed for use in moderate and tropical climates.

 ${\it Ensure adequate ventilation, do not stack.}$

Please read and keep these instructions for your safety and protection.

02] Safety Instructions

Explanation of symbols used in this manual or on the rear/ underside of the apparatus:



This symbol is intended to alert the user to the presence of un-insulated dangerous voltages within the enclosure of sufficient magnitude to cause electric shock.



This symbol is intended to alert the user to the presence of important operation, maintenance and servicing information in the instruction and service manuals.

For apparatus connected to the mains electricity supply:



CAUTION

To reduce the risk of electric shock do not remove the cover. There are no user serviceable parts inside the products. Refer servicing to qualified service personnel.

WARNING

To reduce the risk of fire or electric shock do not expose this apparatus to rain or moisture.

This appliance should be connected to a mains socket outlet with a protective earth connection.

The external rear binding post provided is for connection of **Atlas Grounding leads ONLY** (see manufacturer's web site), no other apparatus or equipment should be connected.

The external rear binding post is a secondary ground connection and should **NEVER** be used as a safety ground connection.

FUSE REPLACEMENT

This appliance is fitted with a fused IEC C14 socket. Should a fuse need replacing and you are competent to do this proceed as follows. (If you are in doubt contact your dealer or an electrical retailer).



- a) Disconnect the unit from mains power. Remove the IEC lead from the socket. Pull out the fuse cover/carrier (indicated) from the IEC socket.
- b) Remove and dispose of the blown fuse. c) Fit a new 10 amp (15A in 120v markets only) approved fuse into the carrier and push the carrier back into the socket.

Always ensure the fuse cover is fitted.

If the fuse cover is missing do not use the socket. Contact your local electrical retailer to obtain a replacement fuse cover.

Fuses are for fire protection and do not protect against electric shock.

INSTALLATION

The unit is ready to use straight from the box; we recommend power hungry devices for example, power amplifiers or integrated amplifiers be connected nearest to the inlet socket and more sensitive devices further away.

To optimize performance, it is recommended that you fit the feet provided to the product. You have two options, attachment of a simple rubber anti-slip foot or a more specialist isolation foot spike. Alternatively, you may decide to mount the unit directly to a wall, in this case you should use suitable fixings (determined by the wall material). It is recommended that you use all four feet mounting holes to mount the unit rigidly to a wall surface.





CE DECLARATION OF CONFORMITY

declares under our sole responsibility that the named apparatus is in conformance with 2006/95/EC (Low Voltage Directive) as amended.

Safety testing conformance to EN 500085-2-4:2009 in conjunction to EN50085-1:2005+A1:2013.

PRODUCT BRAND: Atlas

PRODUCT NAME(s): Eos 2.5em Modular

PRODUCT TYPE: 6 way power distribution unit

The products are CE marked Mar. 2021.



WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE) DIRECTIVE

Waste Electrical and Electronic Equipment Directive Directive 2002/96/EC of the European Parliament and of the Council.

This symbol is shown on this product. It indicates that the product should not be disposed of with regular household waste, but should be disposed of separately. Electrical and electronic equipment can contain materials hazardous to the environment and human health and therefore should be disposed of at a designated waste facility, or returned to your retailer for the appropriate recycling to take place (see www.atlascables.com for further information).

If you wish to dispose of this product (and it still functions), please consider recycling/reusing it by donating it to a charity shop, selling it or part-exchanging it with your retailer. Re-use is the best form of recycling.

Atlas Cables

Unit 5. Block 8. Moorfield Industrial Estate. Troon Road, Kilmarnock, Ayrshire, Scotland KA2 0BA

+44 (0)1563 572666 | atlascables.com

In line with our policy of continuous development, product specifications are subject to change. E&OE. ©2022 Atlas Cables